

# ON • OFF • GONE

## SWITCHBLADE



*Designed specifically for  
Crew Cab Extra Short Bed Trucks*



*Retractable Truck Bed Covers*

- ▲ *Easy to install and remove - anytime, anywhere*
- ▲ *Total truck bed access*
- ▲ *Retracts in seconds*
- ▲ *Allows full rear visibility*

**800-338-3697 ▲ [pace-edwards.com](http://pace-edwards.com)**





# SWITCHBLADE

- ▲ Easy to use
- ▲ No bulky panels
- ▲ No need to climb into truck bed to operate
- ▲ Solid cover security



**CHECK OUT OUR VIDEOS**

Installation Video: <http://www.youtube.com/watch?v=2Fso3Kpz8bk>  
 Action Video: [http://www.youtube.com/watch?v=ffDlgs1m\\_qo](http://www.youtube.com/watch?v=ffDlgs1m_qo)

## FAST ON • FAST OFF



- ▲ Only two tools are needed to quickly install and remove the Switchblade
  - Philips Head Screwdriver
  - 7/16" Wrench

▲ Switchblade Kit Includes:

- Canister
- (2) Two Drain Tubes
- (2) Two Side Rails
- (2) Locator Bolts
- (4) Four Screws
- (4) Four Rail Clamps

1. Center Canister on truck rails and push completely forward.
2. Position rail against the side of the truck's interior bed rail.
3. Slide clamps into the notches in the rail and tighten snugly.
4. Tighten locator bolts.
5. Position the Top Cover on the Canister and mount with (4) four screws.



## 2013 SWITCHBLADE APPLICATION GUIDE

| YEAR  | MODEL                            | BED LENGTH | BOX | KIT      |
|-------|----------------------------------|------------|-----|----------|
|       | <b>CHEVY/GMC</b>                 |            |     |          |
| 04-14 | Silverado 1500 Crew Cab          | 5' 8"      | XSB | SWC3250  |
| 88-13 | C/K/Silverado, Heavy Duty ^      | 6' 6"      | SB  | SWC0303  |
| 2014  | Silverado 1500                   | 6'6"       | SB  | SWC95A17 |
|       | <b>DODGE</b>                     |            |     |          |
| 09-14 | Ram 1500 Crew Cab                | 5' 6"      | XSB | SWD77A01 |
| 09-14 | Ram                              | 6' 3"      | SB  | SWD7833  |
|       | <b>FORD</b>                      |            |     |          |
| 04-14 | Super Crew/SuperCab              | 5' 6"      | XSB | SWF2843  |
| 04-14 | F-Series LightDuty               | 6' 5"      | SB  | SWF29A20 |
|       | <b>TOYOTA</b>                    |            |     |          |
| 07-14 | Tundra CrewMax (*2)              | 5' 5"      | XSB | SWF5379  |
| 07-14 | Tundra Regular & Double Cab (*2) | 6' 5"      | SB  | SWF5173  |



(\*2) Will impede the use of the optional factory cargo management system ▲ ^ Excludes composite box

**1-800-338-3697 ▲ [www.pace-edwards.com](http://www.pace-edwards.com)**