AMP POWEr Step



NTEGRATED



FORD TRUCKS

1999-2011

The AMP Research PowerStep™ seamlessly extends when any door is opened, giving a rocksolid, safe and convenient step up into your truck.

Genuine AMP Research PowerStep™ running boards for Ford F-150 and Super Duty trucks.

Made in USA

- Integrated LED Light System Standard
- High-strength, die-cast aluminum-alloy linkage arms, anodized and Teflon[®] coated to resist corrosion
- Precision, zero-maintenance stainless-steel pivot pins
- Extruded aluminum steps with a textured powder-coat finish for maximum grip and durability
- 600 lb load capacity (each side)
- Weatherproof, OEM-quality electric motors and wiring harness with sealed weather-tight connectors
- AMP-designed electronic controller employs pressure-
- sensitive, pinch-proof safety technology
- 5-Year/60,000 Mile Warranty



AMP Research PowerStep[™] retracts safely under the vehicle keeping the step surface clean, and protected with no loss of ground clearance. Shown in retracted position on a 2010 Ford F-250 Crew Cab.

АМР Рошег Step

FORD TRUCKS 1999-2011

Designed and built exclusively in the USA, the genuine AMP Research PowerStep[™] seamlessly extends when any door is opened, giving a rock-solid, safe and convenient step up into your truck. When the doors close, it retracts just as smoothly, streamlining the vehicle profile with no loss of ground clearance. The original AMP Research PowerStep[™] is proven to perform in severe driving conditions and is backed by a full 5-year/60,000 mile warranty – the best in the business.

AMP RESEARCH POWERSTEP™			
VEHICLE APPLICATION	MODEL YEAR	PART N ^o	NOTE
FORD			
Ford F-150 SuperCab/SuperCrew	2009–2011	75141-01A	
Ford F-150 SuperCab/SuperCrew/Lincoln Mark LT	2004–2008	75105-01A	
Ford F-150 SuperCrew (Heritage)	2001–2003	75111-01A	
Ford Super Duty F-250/F-350/F-450 Regular Cab/SuperCab/CrewCab	2002-2003 / 2008-2011	75134-01A	
Ford Super Duty F-250/F-350/F-450 Regular Cab/SuperCab/CrewCab	1999-2001 / 2004-2007	75104-01A	(2)
Ford Excursion	2000-2001 / 2004-2005	75104-01A	(2)
Ford Excursion	2002–2003	75134-01A	(2)

(2) Diodes required-2004-2007 Ford Super Duty trucks without remote keyless plus 1999 and older Super Duty trucks with remote keyless entry require four (4) additional diodes that are not included in the standard parts kit–When ordering please specify the vehicle model year so that the diodes can be included. If needed, additional diodes (Part # 10-02727-90) may be ordered at no charge and shipped UPS Ground by calling 1-800-983-2206.

POWERSTEP™ EXTRAS

Power Step Extension Arm Kit–Includes four (4) arms. Provides 2-inch extra drop for lifted trucks.

```
75130-01A Ford Super Duty and Dodge Ram only
```



Retracted position – 2010 Ford F-150 Super Crew

Deployed position – passenger side view, Ford F-150 Super Crew

