

WeatherTech® CHEVROLET®

2012



FloorLiner™ • Cargo Liners • Side Window Deflectors • No-Drill MudFlap

FLOORLINER™ (Front)

2012 Silverado Reg Cab	443431
2012 Silverado Reg Cab - Over the Hump	443711
2012 Silverado Ext/Crew Cab/Avalanche	440661
2012 Silverado Ext/Crew Cab - Over the Hump	442941
2012 Tahoe/Suburban	440661
2012 Colorado Ext Cab	440761
2012 Colorado Crew Cab	440091

PART

SIDE WINDOW DEFLECTORS

2012 Silver Std Cab - Dark - 2 Pc Set
2012 Silver Ext Cab - Dark - 4 Pc Set
2012 Silver Crew/Avalanche - Dark - 4 Pc Set
2012 Tahoe - Dark - 4 Pc Set
2012 Suburban - Dark - 4 Pc Set
2012 Colorado Reg Cab - Dark
2012 Colorado Ext Cab - 4 Pc Set - Dark

PART

80426
86426
84426
82426
84426
80339
88339

FLOORLINER™ (Rear)

2012 Silverado Ext Cab
2012 Silverado Crew Cab
2012 Tahoe/Sub Bench/Bucket
2012 Tahoe Bucket - 2nd Row
2012 Avalanche
2012 Colorado Ext Cab
2012 Colorado Crew Cab

PART

440669
440660
440662
442353
440663
440762
440092

No-DRILL MUDDLAPS

2012 Silverado - No Flares - Front
2012 Silverado - No Flares - Rear
2012 Silverado Dually - No Flares Rear
2012 Suburban No RB/Steps/No Z71 - Front
2012 Suburban No RB/Steps/No Z71 - Rear
2012 Tahoe LTZ/Z71/Avalanche w/Flares - Front
2012 Avalanche w/Flares - Rear
2012 Tahoe LTZ/Z71 - Rear
2012 Tahoe/Avalanche w/o Flares - Front
2012 Avalanche w/o Flares - Rear
2012 Tahoe - Rear
2012 Colorado w/o Flares w/factory RB - Front
2012 Colorado w/o Flares w/factory RB - Rear

PART

110010
120010
120025
110008
120004
110013
120022
120004
110008
120016
120015
110032
120032

CARGO LINERS

2012 Suburban - behind 2nd Row
2012 Suburban - behind 3rd Row
2012 Tahoe - behind 2nd Row

PART

40310
40311
40307

Cargo Liners and FloorLiner™ Part Numbers are for BLACK ONLY
 FloorLiner™ Front Order Code: Black = 44XXXX, Tan = 45XXXX, Gray = 46XXXX
 Cargo Liners Order Code: Black = 40XXX, Tan = 41XXX, Gray=42XXX